




6'x3' URBAN GARDEN BED ASSEMBLY MANUAL

Stock Code:
URB63

Version #Pre-Release
Oct 10, 2024



CONTACT

ADDRESS

9393 287th Street,
Maple Ridge, British Columbia,
Canada, V2W 1L1

PHONE & FAX

Toll Free: 1-888-658-1658
Fax: 604-462-5333

ONLINE

Email: olmsupport@outdoorlivingtoday.com
Web: www.outdoorlivingtoday.com

IMPORTANT INFORMATION

1. Selecting a Location - Garden Setting or Patio

Walk around your property and make notes of the following:

- sunny spots
- slope of the land
- light blocking trees and high buildings.

Don't hide your Garden away in a dark corner.

Ensure you have easy access to it. Place your Garden on a level piece of land with good drainage. Take into account existing paths and utilities such as electricity and water. Having a water supply at hand avoids carrying heavy watering cans from the tap to the raised bed.

2. Preparing the Ground for a Garden Setting

Level ground beneath the raised bed prior to assembly. Your new Garden will be open on the bottom which enables plant roots to access soil nutrients below ground level.

Lay down a sand perimeter base for the garden frames to sit on if possible. Sand offers excellent drainage and will make it easier to level bed frames.

The Garden can also be located on almost any flat surface - sand, pebbles/gravel, concrete or asphalt. Preparing the soil and the sand base beneath the garden will not be necessary. Twenty inches of soil should be plenty for most types of vegetables and flowers. Please check growing instructions for root depths prior to planting.

3. Adding a Liner

- Consider lining the Garden with landscape fabric (not included) to prevent soil from seeping out. Liners also provide insulation for the soil and helps control temperature fluctuations. In addition, liners separate weeds from seeds and can drive away pests like gophers and moles that can damage your plants.

Note: Raised Garden Beds qualify for our Limited 3-Year Warranty only if the interior of the beds is fully lined with a waterproof barrier before filling the Garden with soil.

4. Arranging and Planting Crops

Since requirements vary from region to region on how to arrange and plant crops, we recommend researching thoroughly before planting

5. Warranty Considerations

- Failure to use the supplied parts included in this kit could result in poor product performance and may void your warranty.
- If you plan to deviate from our written instructions, please contact Outdoor Living Today's Customer Toll-Free Line for guidance.

6. Liability and Customer Support

- Customers agree to hold Outdoor Living Today and any Authorized Dealers free of any liability for improper installation, maintenance, and repair.
- In the event of a missing or broken piece, contact the Outdoor Living Today Customer Support Line at 1-888-658-1658 within 30 days of delivery. Replacement parts will be couriered free of charge within 10 business days.
- All structures purchased from Outdoor Living Today are covered for one year against defects in manufacturing and workmanship. Costs incurred for customer installations are not included.

KEY FEATURES

- Double-Walled Aluminum Connectors

Rust-proof, 1/8" thick Black Anodized 6063-T6 Aluminum corner and 'T' connectors for enhanced strength and durability without the need for interior bracing.

- Pre-Drilled for Easy Assembly

All components come pre-drilled, allowing for a fast, tool-free setup that requires minimal effort.

- Contemporary Design

The combination of sleek cedar wood and modern aluminum connectors ensures a stylish addition to any outdoor space, blending functionality with aesthetic.

- Premium Cedar Construction

Made from high-quality, locally sourced Western Red Cedar for natural resistance to rot, decay, and pests, ensuring long-lasting performance.

- 22.5-Inch High Growing Beds

Provides ample depth for planting a variety of vegetables, herbs, fruits, and flowers, ensuring healthier root development.

- 33% Thicker Design

Boasting a full 1-inch thickness, this raised bed offers increased durability and structural strength compared to competitors.

- Included Floor

Designed to keep soil in place while providing a stable base for your plants. Transform your gardening experience with our Urban Raised Garden Bed

WHAT TO DO BEFORE YOUR GARDEN ARRIVES



Become familiar with this assembly manual and determine if you can complete the project yourself or will require a professional contractor.



Clear the construction area and ensure a clear pathway for delivery when the freight company arrives. Remove all debris: roots, grass, rocks, etc.











If doing the assembly yourself, have all the necessary tools ready to go and in working condition. A list of required tools can be found after the parts list.



One helper is recommended to assist in constructing your garden.



**Thank you for purchasing our 6'x3' Urban Garden Bed
Please take the time to identify all the parts prior to assembly.**

PARTS LIST

PART DRAWING	CROSS SECTION	QUANTITY	LENGTH	PART NAME & DIMENSIONS
		4	22.5	Corner Bracket 1/8" x 2 13/16" x 22 1/2"
		2	22.5	Aluminum T Bracket 1/8" x 4 5/16" x 22 1/2"
		49	33	Panel Boards 1" x 4 1/2" x 33"
		4	33	Floor Cleat 1 1/2" x 1 1/2" x 33"

Note: you may find the detailed drawings at the end of the manual.

HARDWARE KIT (PROVIDED)

2" Brown Screw  x 44	3/4" Black Headed Screw  x 140
---	---

TOOLS REQUIRED (NOT PROVIDED)

Shovel 	Screw Gun/Drill 	Tape Measure 
Level 	Fabric Liner	

SAFETY EQUIPMENT REQUIRED (NOT PROVIDED)

Safety Glasses 	Work Gloves 
---	--

To prevent soil seepage and extend the life of your garden bed, we recommend you line the inner walls with landscape fabric or plastic sheeting (not provided) before filling with soil.


HELPFUL TIPS FOR ASSEMBLY




Follow Symbols



Have Helper



Build on Level
Foundation



Check
Measurements
are Square

SYMBOLS

Throughout this assembly manual, symbols are provided at the top right-hand corner of the assembly step:



Use Help

Use help where this is shown. Two or more people are required to safely complete this step. To avoid injury or damage to the assembly, make sure to get some help.



Pre-Drill

Pre-drill a pilot hole before fastening screw or lag to prevent splitting of wood.



Use a Measuring Tape

Use a measuring tape to assure proper location.



Use a Clamp

Use a clamp to help fasten parts together.

1. Wall Section



1. Locate 2 - Corner Brackets and 1 - Panel Board. Press the Corner Brackets tight over the Panel Board. Screw each Corner Bracket to the Panel Board with 4 - 3/4" Black Screws. When selecting the boards choose the most desirable face to be on the outside.

Pieces:

- 1x Panel Board
(1" x 4 1/2" x 33")

Hardware:

- 2x Corner Brackets
- 4x 3/4" Black Screws




2. Continue adding Panel Boards and screwing them in with 4 - 3/4" screws per piece until 5 boards have been stacked up and one side of the garden bed is complete.

Pieces:

- 4x Panel Board
(1" x 4 1/2" x 33")

Hardware:

- 16x 3/4" Black Screws



3. Position one Panel Board tight inside the Corner Bracket on one end of the garden bed and fasten with 4 - 3/4" Black Screws. Continue adding and fastening boards until the top of this side is reached.

Pieces:
 - 5x Panel Board
 (1" x 4 1/2" x 33")

Hardware:
 - 20x 3/4" Black Screws



4. Locate 1 - T Bracket. Install T Bracket over previously installed boards with 10 - 3/4" Black Screws.

Pieces:


Hardware:
 - 1x T Bracket
 - 10x 3/4" Black Screws



5. Position one Panel Board tight inside the Corner Bracket on one end of the garden bed and fasten with 4 - 3/4" Black Screws. Continue adding and fastening boards until the top of this side is reached.

Pieces:
 - 5x Panel Board
 (1" x 4 1/2" x 33")

Hardware:
 - 10x 3/4" Black Screws



6. Position Corner Bracket tight to side. Fasten Corner Bracket to previously installed side of garden bed with 10 - 3/4" Black Screws.

Pieces:



Hardware:
 - 1x Corner Brackets
 - 10x 3/4" Black Screws



7. Continue adding Panel Boards and screwing them in with 4 - 3/4" screws per piece until 5 boards have been stacked up and one side of the garden bed is complete.

Pieces:
 - 5x Panel Board
 (1" x 4 1/2" x 33")



Hardware:
 - 10x 3/4" Black Screws



8. Install the remaining T Bracket over previously installed boards with 10 - 3/4" Black Screws.

Pieces:


Hardware:
 - 1x T Bracket
 - 10x 3/4" Black Screws



9. Position Panel Boards inside T Brackets. Push built sides in to ensure a tight fit before fastening boards with 4 - 3/4" Black Screws per piece until the top of this side is reached.

Pieces:
- 5x Panel Board
(1" x 4 1/2" x 33")


Hardware:
- 20x 3/4" Black Screws



10. Continue adding Panel Boards and screwing them in with 2 - 3/4" Black Screws per piece until 5 boards have been stacked up and one side of the garden bed is complete.

Pieces:
- 5x Panel Board
(1" x 4 1/2" x 33")

Hardware:
- 10x 3/4" Black Screws




11. Position final remaining Corner Bracket tight to finished side with 2 - 3/4" Black Screws.

Pieces:

Hardware:

- 1x Corner Brackets
- 10x 3/4" Black Screws



12. Position Panel Boards and screwing them in with 4 - 3/4" Black Screws per piece until 5 boards have been stacked up and sides of the garden bed are complete.


Pieces:

Hardware:

- 5x Panel Board
(1" x 4 1/2" x 33")

- 20x 3/4" Black Screws



2. Floor Section



13. Locate the 4 - Floor Cleats and position them near the bottom of the raised bed. Fasten the floor Cleats to the side walls with 4 - 2" Brown Screws each. Fasten a Floor Cleat to each side of the garden bed.

Pieces:
 - 4x Floor Cleat
 (1 1/2" x 1 1/2" x 33")

Hardware:
 - 16x 2" Brown Screws



14. Locate the remaining 8 Floor Boards spread them out evenly over the Floor Cleats, leaving approximately 1/4" in between each floor board. Fasten Floor Boards to Floor Cleat with 2 - 2" Brown screws per piece.

Pieces:
 - 14x Floor Boards
 (1 1/2" x 4 1/2" x 33")

Hardware:
 - 28x 2" Brown Screws


3. Liner Section



15. Line the garden bed with landscaping fabric and tuck into the sides.

Pieces:
- 1x Fabric Liner

Hardware:




16. Fill the garden bed with 15 - 16 cubic feet of soil depending on how low the floor is installed. Plant the garden and enjoy.


Pieces:

Hardware:


Front Profile




Back Profile




Left Profile




Right Profile



Top Profile




Bottom Profile



We strongly recommend you now line the inner walls of your Garden in a Box with landscape fabric or 6 mil poly/plastic sheeting (not provided) before filling with soil.

Note: Raised Garden Beds qualify for our Limited 3-Year Warranty only if the interior of the beds is fully lined with a waterproof barrier before filling the Garden with soil.



Congratulations on assembling your 6x3 Urban Garden Bed!

We hope your experience constructing our **6x3 Urban Garden Bed** has been both positive and rewarding. We value your feedback and would like to hear back from you on how well we are doing in the following areas:

- 1. Customer Service**
- 2. On Time Shipping**
- 3. Motor Freight Delivery**
- 4. Quality of Materials**
- 5. Assembly Manual**
- 6. Overall Satisfaction**



The materials contained in this Assembly Manual may be downloaded or copied provided that ALL copies retain the copyright and any other proprietary notices contained on the materials. No material may be modified, edited or taken out of context such that its use creates a false or misleading statement or impression as to the positions, statements or actions.

Please call, write or email us at:

Canadian Address
9393 287th Street
Maple Ridge, British Columbia
Canada V2W 1L1

United States Address
P.O. Box 96
Sumas, Washington
USA 98295

Toll Line: 1.888.658.1658 | **Fax: 1.604.462.5333** | **sales@outdoorlivingtoday.com**