




Version #1.0
Nov 26th, 2021

12x8 Cabana Garden Shed Interior Wall Kit Assembly Manual

Thank you for purchasing a 12x8 Cabana Garden Shed Interior Wall Kit. Please take the time to identify all the parts prior to assembly.



Customer agrees to hold Outdoor Living Today and any Authorized Dealers free of any liability for improper installation, maintenance and repair.

In the event of a missing or broken piece, call the Outdoor Living Today Customer Support Line @ 1-888-658-1658 within 30 days of the delivery of your purchase. It is our commitment to you to courier replacement parts, free of charge, within 10 business days of this notification. Replacement parts will not be provided free of charge after the 30 day grace period.

All structures purchased from Outdoor Living Today are covered for a period of one year for defects in manufacturing and workmanship. Costs incurred for customer installations are not included.



Failure to use supplied parts included in this kit could result in poor product performance and may void your warranty. Please contact Outdoor Living Today's Customer Toll Free Line if you plan to deviate from our written instructions.

**Thank you for purchasing our 12x8 Cabana Garden Shed Interior Wall.
Please take the time to identify all the parts prior to assembly.**

A. Wall Components 1A: 1 - 42 3/4"w x 75 1/4"h - Rear Solid Wall Panel Left ----- 2A: 1 - 42 3/4"w x 75 1/4"h - Rear Solid Wall Panel Right ----- 3A: 1 - 45 1/2"w x 75 1/4"h - Rear Solid Wall Panel Center ----- 4A: 4 - 45 1/4"w x 75 1/4"h - Side Solid Wall Panel L/R ----- 5A: 2 - 42 3/4"w x 75 1/4"h - Front Window Wall Panel L/R ----- 6A: 1 - 11 3/4"w x 75 1/4"h - Front Narrow Wall Panel ----- 7A: 4 - 45"w x 18"h - Triangular Gable Panel L/R -----	Steps ↓ 10 11 12 17-18 14-15 16 19-20
B. Plywood Components 1B: 2 - 3/8" x 45 1/2" x 48" - Ceiling Plywood Center ----- 2B: 4 - 3/8" x 42 3/4" x 48" - Ceiling Plywood L/R ----- 3B: 1 - 3/8" x 31 3/8" x 29 3/16" - Top Door Plywood ----- 4B: 1 - 3/8" x 31 3/8" x 41 3/16" - Bottom Door Plywood -----	Steps ↓ 3 2 23 24
C. Trim Components 1C: 4 - 3/4" x 2 1/2" x 46" - Ceiling Gable Cleats ----- 2C: 4 - 1 1/2" x 2 1/2" x 12" - Interior Wall Cleats ----- 3C: 1 - 3/4" x 3 1/2" x 31 1/2" - Top Plate for Bottom Dutch Door ----- 4C: 4 - 1/4" x 2" x 73 1/4" - Vertical Wall Trim ----- 5C: 4 - 1/4" x 2" x 46 7/8" - Vertical Wall Trim (45° cut one end) ----- 6C: 4 - 1/4" x 2" x 64 7/8" - Horizontal Wall Trim ----- 7C: 4 - 1/4" x 2" x 58" - Gable Trims (22.5° cut one end, reverse opposite end) ----- 8C: 4 - 1/4" x 2 1/2" x 48" - Ceiling Trims ----- 9C: 2 - 2 1/2" x 5" x 52" - Ceiling Gussets ----- 10C: 1 - 7/8" x 2" x 73" - Vertical Door Trim (Jamb side) ----- 11C: 1 - 7/8" x 1 1/2" x 33 1/2" - Horizontal Door Trim ----- 12A: 1 - 1/2" x 7/8" x 73" - Vertical Door Trim (Narrow Wall Side) ----- 13C: 2 - 21 7/8" x 26 1/2" - Large Window Inserts ----- 14C: 2 - 3/4" x 5" x 67 3/8" - Ridge Cap Trims -----	Steps ↓ 1 9 21-22 17 31 28 30 7 8 25 27 26 32 6

12X8 Cabana Interior Wall Kit **HARDWARE PACKAGE**

Hardware Kit (Provided)



Tools Required (Not Provided)



Safety Equipment Required (Not Provided)



Optional Materials and Tools - Not Included in Kit

Materials to Insulate Shed prior to installing Interior Wall Kit

2" thick Foam Board Insulation
550 sq ft. (covers walls and ceiling)

180 sq ft additional for floor

6 mm Poly - Air Vapor Barrier -

Tools -


Staple Gun

Utility Knife

Caulking Gun and Caulking

A. Ceiling Section


Exploded view of all parts necessary to complete Interior Ceiling Section. Please Identify all parts prior to starting your project.



1. Locate Ceiling Gable Cleats. Position cleat on top of gable framing tight against rafter. Clamp and screw to gable frame with **3 - 2 1/2" screws**.

Parts
1C - Ceiling Gable Cleats
 (3/4" x 2 1/2" x 46") x 4


Hardware
S1 - 2 1/2" Screws
 x 12 total



2. Locate Ceiling Plywood L/R and position up against rafter and ceiling gable cleat. Position squarely and attach with **9 - 1 1/4" screws.** Fasten to rafters and gable cleat.

Parts
2B - Ceiling Plywood L/R
 (3/8" x 42 3/4" x 48") x 1


Hardware
S2 - 1 1/4" Screws
 x 9 total



3. Locate Ceiling Plywood Center and position up against rafters. Position squarely and attach with **9 - 1 1/4" screws.**

Parts
2B - Ceiling Plywood Center
 (3/8" x 45 1/2" x 48") x 1



Hardware
S2 - 1 1/4" Screws
 x 9 total



4. Locate Ceiling Plywood L/R and position up against rafter and ceiling gable cleat. Position squarely and attach with **9 - 1 1/4" screws.** Fasten to rafters and gable cleat as per **Step 2.**

Parts
2B - Ceiling Plywood L/R
 (3/8" x 42 3/4" x 48") x 1



Hardware
S2 - 1 1/4" Screws
 x 9 total



5. Repeat **Steps 2 - 4** to attach ceiling plywood to remaining side of roof.

Hardware
S2 - 1 1/4" Screws
 x 27 total



Parts
2B - Ceiling Plywood L/R
 (3/8" x 42 3/4" x 48") x 2
2B - Ceiling Plywood Center
 (3/8" x 45 1/2" x 48") x 1



6. Locate Ridge Cap Trims and position evenly underneath ridge board. Fasten Ridge Trims with **6 - 1 1/2" Finishing Nails** each.

Parts
14C - Ridge Cap Trim
 (1/4" x 2 1/2" x 48") x 4



Hardware
N1 - 1 1/2" Finishing
 x 12 total



7. Locate Ceiling Trims and position evenly over seams in Ceiling Plywood. Fasten Ceiling Trims with **6 - 1 1/2" Finishing Nails** each.

Parts
8C - Ceiling Trims
 (1/4" x 2 1/2" x 48") x 4

Hardware
N1 - 1 1/2" Finishing
 x 24 total



8. Locate both Ceiling Gussets. On a ladder, position 1st Gusset evenly against ceiling trim. Drill pilot holes with appropriate angles before fastening. Secure with **2 - 4" Torx screws** per side. Complete both gussets. Torx drive bit required.

Parts
8C - Ceiling Gusset
 (2 1/2 x 5" x 52") x 2

Hardware
ST2 - 4" Torx Screw
 x 8 total

B. Wall Section



9. Position Interior Wall Cleats against rear wall in corner. Attach each Cleat with **2 - 2 1/2" screws**. Attach cleats to each corner of your shed. Cleat provides an edge to screw Interior Wall Panel to in **Step 10 & 14**.

Parts
2C - Interior Wall Cleats
 (1 1/2" x 2 1/2" x 12") x 4


Hardware
S1 - 2 1/2" Screws
 x 8 total



10. Locate Left Solid Wall Panel (42 3/4" wide). The left panel will have wall siding recessed on the left side as illustrated above. Position on wall studs and secure with **6 - 1 1/4" screws**.

Parts
1A - Solid Wall Panel Left
 (42 3/4"w x 75 1/4") x 1


Hardware
S2 - 1 1/4" Screws
 x 6 total



11. Locate Right Solid Wall Panel (42 3/4" wide). The right panel will have wall siding recessed on the right side as illustrated above. Position on wall studs and secure with **6 - 1 1/4" screws.**

Parts
2A - Solid Wall Panel Right
(42 3/4"w x 75 1/4") x 1


Hardware
S2 - 1 1/4" Screws
x 6 total



12. Locate Rear Solid Wall Panel (45 1/2" wide). Center Wall Panel has siding flush with plywood backing. Position between previously installed panels and secure with **6 - 1 1/4" screws.**

Parts
3A - Solid Wall Panel Center
(45 1/2"w x 75 1/4") x 2

Hardware
S2 - 1 1/4" Screws
x 6 total



13. Locate Rear Solid Wall Panel (45 1/2" wide). Center Wall Panel has siding flush with plywood backing. Position between previously installed panels and secure with **6 - 1 1/4" screws.**

Parts
3A - Solid Wall Panel Center
(45 1/2"w x 75 1/4") x 2

Hardware
S2 - 1 1/4" Screws
x 6 total



14. Locate Front Window Wall Panel (42 3/4" wide). Window Wall Panel has siding recessed from plywood backing. Position in front of interior wall cleats as per **Step 10** and secure with **6 - 1 1/4" screws**.

Parts
5A - Front Window Wall Panel
 (42 3/4"w x 75 1/4") x 1

Hardware
S2 - 1 1/4" Screws
 x 6 total



15. Locate second Front Window Wall Panel (42 3/4" wide). Window Wall Panel has siding recessed from plywood backing. Position in front of interior wall cleats as per **Step 14** and secure with **6 - 1 1/4" screws**.

Parts
5A - Front Window Wall Panel
 (42 3/4"w x 75 1/4") x 1

Hardware
S2 - 1 1/4" Screws
 x 6 total



16. Locate Narrow Wall Panel (11 3/4" wide). Position in front of narrow wall and secure with **6 - 1 1/4" screws**.

Parts
6A - Narrow Wall Panel
 (11 3/4"w x 75 1/4") x 1

Hardware
S2 - 1 1/4" Screws
 x 6 total

Side Panel flush with plywood of Rear Wall Panel in Corner




17. Locate Side Wall Panel (45 1/4" wide). Position in rear corner. Slide edge tight in corner against rear wall plywood backing. Secure with **6 - 1 1/4" screws**.

Parts
4A - Side Wall Panel
(45 1/4"w x 75 1/4") x 1

Hardware
S2 - 1 1/4" Screws
x 6 total


Side Panel flush with plywood of Rear Wall Panel in Corner



18. Repeat **Step 17** to place a Side Wall Panel (45 1/4" wide) in each corner of the shed. Slide edge tight in corner against rear/front wall plywood backing. and secure with **6 - 1 1/4" screws**.

Parts
4A - Side Wall Panel
(45 1/4"w x 75 1/4") x 3



Hardware
S2 - 1 1/4" Screws
x 18 total



19. Locate Triangular Gable Panel. Position over Gables. Siding on bottom of Gable Panel will overhang Side Wall Panel as shown above. Secure with **6 - 1 1/4" screws.**

Parts
7A - Triangular Gable Panel
 L/R
 (45" w x 18") x 1

Hardware
S2 - 1 1/4" Screws
 x 4 total




20. Locate remaining Triangular Gable Panels. Position over Gables. Secure panels with **6 - 1 1/4" screws.** as per **Step 19** on both sides.

Parts
7A - Triangular Gable Panel
 L/R
 (45" w x 18") x 3

Hardware
S2 - 1 1/4" Screws
 x 12 total




21. To accommodate Interior Door Plywood, the existing top plate on bottom door must be removed first. Using a hammer, carefully pry off the top plate and remove any hardware.



22. Position replacement top plate on bottom door and attach with **6 - 1 1/2" Finishing Nails**. Replacement Top Plate will cap door siding.

Parts
3C - Top Plate for Bottom Dutch Door
 (3/4" x 3 1/2" x 31 1/2") x 1


Hardware
N1 - 1 1/2" Finishing Nails
 x 6 total



23. Position top door plywood over door framing. Confirm it is evenly spaced on door framing and attach with **12 - 1 1/2" finishing nails**.

Parts
3B - Top Door Plywood
 (3/8" x 31 3/8" x 29 3/16") x 1

Hardware
N1 - 1 1/2" Finishing Nails
 x 12 total





24. Position bottom door plywood on door. Position tight under new top cap and attach with **12 - 1 1/2" finishing nails**.

Parts
4B - Bottom Door Plywood
 (3/8" x 31 3/8" x 41 3/16") x 1

Hardware
N1 - 1 1/2" Finishing Nails
 x 12 total


C. Trim Section



25. Locate all 3 door stops. Start on the door jamb side, position 2" wide stop against door jamb and the edge of wall siding. Attach with **4 - 1 1/4" screws.**

Parts
1C - Vertical Door Stop - Jamb
 (7/8" x 2" x 73") x 1


Hardware
S2 - 1 1/4" Screws
 x 4 total



26. Position and attach the narrow wall door stop on framing with **6 - 1 1/2" finishing nails.**

Parts
2C - Vertical Door Stop - Narrow Wall
 (7/8" x 1/2" x 73") x 1


Hardware
N1 - 1 1/2" Finishing Nails
 x 6 total



27. To complete the door stops, attach the Horizontal Door Stop against Door Header and attach with **3 - 1 1/4" screws.**

Parts
3C - Top Horizontal Door Stop
 (7/8" x 1 1/2" x 33 1/2") x 1


Hardware
S2 - 1 1/4" Screws
 x 3 total



28. Locate Horizontal Wall Trims. Position up against wall siding and below ceiling plywood. Attach with **8 - 1 1/2" Finishing Nails** each. Complete front and rear with all 4 pieces.

Parts
6C - Horizontal Wall Trims
 (1/4" x 2" x 64 7/8") x 4


Hardware
N1 - 1 1/2" Finishing Nails
 x 32 total



29. Locate Vertical Wall Trims. Position over seams in side walls on both sides of shed. Attach each piece with **6 - 1 1/2" Finishing Nails**. Complete both front and rear.

Parts
4C - Vertical Wall Trims
 (1/4" x 2" x 73 1/4") x 4



Hardware
N1 - 1 1/2" Finishing Nails
 x 12 total



30. Locate Gable Trims. Position against Gable Wall siding and bottom of ceiling plywood. Trims will but up against Rodge Trim and Horizontal Wall Trims. Attach each piece with **6 - 1 1/2" Finishing Nails**. Complete both sides of shed.

Parts
7C - Gable Trims
 (1/4" x 2" x 49 1/4") x 4


Hardware
N1 - 1 1/2" Finishing Nails
 x 24 total



31. Locate remaining Vertical Wall Trims. Vertical Wall have a straight cut end and a bevel cut end. The bottom trim may need to be chopped at the bottom to fit your ceiling position. Both pieces have a bevel cut where they meet in the middle. Attach each piece with **3 - 1 1/2" Finishing Nails**. Cover remaining seams on side walls.

Parts
4C - Vertical Wall Trims
 (1/4" x 2" x 46 7/8") x 4


Hardware
N1 - 1 1/2" Finishing Nails
 x 12 total



32. Locate the 2 large Window Inserts and position in window cavity. Nail to window wall framing with **9 - 1 1/2" Finishing Nails** from the bottom and sides. Complete both Windows.

Parts
13C - Large Window Inserts
 (21 7/8" x 26 1/2") x 2

Hardware
N1 - 1 1/2" Finishing Nails
 x 18 total



33. Attach barrel bolt to door plywood. Male bolt attached to top while female to bottom door. Attach door handle to top door. Use 3/4" black headed screws for both pieces.

Parts
Barrel Bolt & Door Handle

Hardware
SB1 - 3/4" Black Head Screws
 x 12 total



Congratulations on assembling your 12x8 Cabana Garden Shed Interior Wall Kit!



We value your feedback and would like to hear back from you on how well we are doing in the following areas:

1. **Customer Service**
2. **On Time Shipping**
3. **Motor Freight Delivery**
4. **Quality of Materials**
5. **Assembly Manual**
6. **Overall Satisfaction.**

Please call, write or email us at:

Outdoor Living Today

Canadian Address
9393 287th Street
Maple Ridge, British Columbia
Canada V2W 1L1

United States Address
P.O. Box 96
Sumas, Washington
USA 98295



The materials contained in this Assembly Manual may be downloaded or copied provided that ALL copies retain the copyright and any other proprietary notices contained on the materials. No material may be modified, edited or taken out of context such that its use creates a false or misleading statement or impression as to the positions, statements or actions.